

FIG. 1




FIG. 2




FIG. 3




FIG. 4




FIG. 5

REMOTE VEHICLE POSITION
REQUEST MESSAGE

OPR	REQUESTING VEHICLE ID	REQUESTED VEHICLE ID
-----	--------------------------	-------------------------

OPR: REMOTE VEHICLE POSITION
REQUEST CODE

FIG. 6




FIG. 7

VEHICLE POSITION SPONTANEOUS
TRANSMISSION MESSAGE

CPT	ORIGINATING VEHICLE ID	DESTINATION VEHICLE ID	VEHICLE POSITION INFORMATION
-----	---------------------------	---------------------------	---------------------------------

CPT: VEHICLE POSITION
SPONTANEOUS TRANSMISSION CODE

FIG. 8

VEHICLE POSITION REQUEST MESSAGE			
CPR	REQUESTING VEHICLE ID	REQUESTED VEHICLE ID	MESSAGE NUMBER

CPR: VEHICLE POSITION REQUEST CODE

FIG. 10

RETURN VEHICLE POSITION MESSAGE			
RCP	REQUESTING VEHICLE ID	REQUESTED VEHICLE ID	MESSAGE NUMBER MN VEHICLE POSITION INFORMATION

RCP: RETURN VEHICLE POSITION CODE

FIG. 11




FIG. 12

RETURN VEHICLE
POSITION MESSAGE

RCP	REQUESTING VEHICLE ID	REQUESTED VEHICLE ID	MESSAGE NUMBER MN	ERR1
-----	--------------------------	-------------------------	-------------------	------

RCP : RETURN VEHICLE POSITION CODE
ERR1 : FIRST ERROR CODE

FIG. 13

RETURN VEHICLE
POSITION MESSAGE

RCP	REQUESTING VEHICLE ID	REQUESTED VEHICLE ID	MESSAGE NUMBER MN	ERR2
-----	--------------------------	-------------------------	-------------------	------

RCP : RETURN VEHICLE POSITION CODE
ERR2 : SECOND ERROR CODE

FIG. 14




FIG. 15

(REMOTE VEHICLE POSITION DISPLAY MODE)




FIG. 16

